




Quick Installation Guide



Wireless AP
M0304346 V1.0

1 Single Device Configuration

1.1 Connection Diagram



1.2 Set the computer to obtain the IP address automatically, and connect the LAN port of the device to the device management interface.

2 4G Internet Mode Setting

- (1) The device defaults to 4G Internet access mode.
- (2) Insert the MACRO SIM according to the device mark before powering up.
- (3) Power on the device, connect the wireless SSID of the device (default is COMFAST_XXXX_2G, XXXX is the last 4 digits of MAC) or connect the device LAN port to the PC through the network cable.
- (4) Open the browser, enter 192.168.10.1 (the mobile terminal can automatically pop up), set the login password, and enter the page to check whether the device has read the SIM card.

Normal read status:

Status

Device Info

MAC: 40:A5:EF:12:45:56
Model: CF-E5
Version: V2.6

4G

Carriers: China Mobile
Network: LTE
RSSI: -57dbm

Unread to SIM:

Status

Device Info

MAC: 40:A5:EF:12:45:56
Model: CF-E5
Version: V2.6

4G

No SIM card detected

(5) If read normally, you need to modify the wireless SSID and password. Enter the menu bar on the left, Network Management - Modify the wireless settings, click on the settings after modifying.


Note:

1. If the SIM card is not read: (1) First check if the SIM card is inserted in the direction of the mark (2) Check if the SIM card has a PIN lock. If there is a lock, please unlock the SIM card with the mobile phone first.
2. Individual operators may prompt Unkown, but the network access information and signals are normal. This do not affect the Internet access.
3. Replacing and plugging the SIM card requires restarting the device.
4. If your card needs to manually set the APN account, please refer to the manual Router Set 4G mode.


3 Other Mode Internet Settings

3.1 The steps to enter the set interface as follows:

- (1) Under default configuration, power on the device and wait 90 seconds untill the device to start.
- (2) Connect the device' s LAN port with the computer by a network cable.
- (3) Input 192.168.10.1 in the web browser to enter the set interface.
- (4) Open the computer browser, and input 192.168.10.1 to get into the device login page. The device is defaulted as Router Mode. When you login at the first time, you need to set a password. The device language is compatible with Chinese and English to choose, and you can set up the language by the top right corner icon 🌐



3.2 When getting into the setting page, there are four working modes in the Wizard: AP Mode, Bridge Mode, Router Mode, Repeater Mode.



3.3 Click AP mode and set up IP Address and Subnet Mask. The IP address and Subnet mask should be within the same network segment as upper network and can't be conflict with IP address from upper network router. After settings, you can visit the device from the IP address you have set just now by connecting internet with LAN port of the device.

①Notes: In AP mode, the IP address from the other devices connected the AP will be allocated by the upper network router.

② The AP needs to set an intranet IP address (do not set the same IP address as the upper router). If want to manage the device, Manually set the IP address of the same network segment of the intranet IP.

Progress: ① Lan Settings ② WiFi 2.4G ③ WiFi 5.8G ④ Finish

Lan Settings

IP Address: 192.168.10.1

Subnet Mask: 255.255.255.0

Next

3.4 AP mode: You can set up 2.4G/5.8G wireless SSID, password, channel and country in advance. After setting up, the device's LAN port connected internet, other mobile devices can connect the SSID to surf the internet.

Note: If the device is 2.4G, the 5.8G wireless setting function is not supported.

Progress: ① Lan Settings ② WiFi 2.4G ③ WiFi 5.8G ④ Finish

2.4G Wireless

SSID: COMFAST_E32B_2G

Password:

Advanced Setting

Bandwidth: 20MHz

Country: China

Channel: auto

Prev Next

3.5 Bridge Mode: Pls ensure the WDS in upper network is enabled. AP device can set up intranet segment (do not set the same IP address as the upper router), and then select the wireless SSID signal you need to bridge (Distinguish between 5.8GHz and 2.4GHz) and input wireless password.
(Notes: The password is same as your upper network router)

① — ② — ③ — ④ — ✓
Lan Settings Bridge Settings WiFi 2.4G WiFi 5.8G Finish

Lan Settings

IP Address

Subnet Mask

Next

Scan Results Refresh

NO.	BSSID	SSID	Channel		Operation
1	40:A5:EF:84:E6:34	unknown	1	🔒 📶	✏️
2	40:A5:EF:84:DE:64	unknown	1	🔒 📶	✏️
3	40:A5:EF:85:48:21	unknown	2	🔒 📶	✏️
4	00:E0:4C:81:96:D1	2.4G_COMFAST_8796C2	2	📶	✏️
5	40:A5:EF:84:E6:31	unknown	1	🔒 📶	✏️
6	40:A5:EF:84:DE:61	unknown	1	🔒 📶	✏️
7	40:A5:EF:80:97:36	E325N_809736	2	📶	✏️

Pls set the SSID and password for the device and click “Next” to finish settings.

① — ② — ③ — ④ — ✓
Lan Settings Bridge Settings WiFi 2.4G WiFi 5.8G Finish

2.4G Wireless

SSID

Password

Prev Next

3.6 Repeater Mode: The AP device can set the internal network segment (the gateway IP should not be the same as the upper device gateway IP). Next, select the name of the wireless SSID signal that you need to relay (distinguish between 5.8GHz and 2.4GHz).

The screenshot shows a configuration interface with a progress bar at the top containing five steps: 1. Lan Settings (highlighted in orange), 2. Repeater Settings, 3. WiFi 2.4G, 4. WiFi 5.8G, and 5. Finish (marked with a checkmark). Below the progress bar, the 'Lan Settings' section is active, showing two input fields: 'IP Address' with the value '192.168.10.1' and 'Subnet Mask' with the value '255.255.255.0'. A 'Next' button is located at the bottom right of the form.

Pls set the SSID and password for the device and click "Next" to finish settings.

The screenshot shows the same configuration interface with the progress bar updated: 1. Lan Settings, 2. Repeater Settings (highlighted in orange), 3. WiFi 2.4G, 4. WiFi 5.8G, and 5. Finish. The '2.4G Wireless' section is now active, displaying two input fields: 'SSID' with the value 'COMFAST_E32B_2G' and an empty 'Password' field. 'Prev' and 'Next' buttons are positioned at the bottom right of the form.

3.7 Router Mode: There are four ways to surf the internet: PPPOE, 4G, Static, and DHCP.

4G Mode: In this mode, you can select automatic APN or manually set the APN account (the APN account is provided by the operator).

① — ② — ③ — ✓
WAN Settings Lan Settings WiFi 2.4G Finish

WAN Settings

☒ 4G ☐ PPPoE ☐ Static ☐ DHCP

APN Config

APN

Username

Password

Next

Pls set the SSID and password for the device and click "Next" to finish settings.

① — ② — ③ — ✓
WAN Settings Lan Settings WiFi 2.4G Finish

2.4G Wireless

SSID

Password

Advanced Setting

Bandwidth

Country

Channel

Prev Next

Quick Installation Guide

Statement

**Shenzhen Four Seas Global Link Network
Technology CO.,Ltd.Company
all rights reserved.**

Without ours official writ permission, no unit or individual shall be copied, reproduced, transcribed or translated in part or whole book. In any form or by any means(electronic,mechanical,printing,recording or other possible means)or for the propagation of goods any commercial, profitable purposes.

COMFAST is the registered trademark of Shenzhen Four Seas Global Link Network Technology Co.,Ltd.Company. All other trademarks or registered trademarks mentioned in this document, by respective owners.

Product specifications and information mentioned in this manual are for reference on subject to updates without notice. Unless there are other special agreed, this manual is used only as a user guide. All statements, information, etc. are not constitute any form of guarantee.

Manufacturer: Shenzhen Four Seas Global Link Network
Technology Co.,Ltd.Company
Address: Room 607-610,Block B Tao JINDI Electronic
Business Incubation Base, Tenglong Road, Longhua District,
Shenzhen, China
Hotline: 0755 83790059/83790659
Website: www.szcomfast.com